X4 REAR ARM INSTRUCTIONS











PART B TOP MOUNTING ARM



PART G THIN SCREWS & WASHERS







PART H LARGE PLASTIC **SCREWS**







PART I X4 SLIDER & SMALL SCREWS



PART E LARGE METAL **SCREWS**















2

X4 REAR ARM INSTRUCTIONS



Connect the Base Mounting Arm (Part A) and screw the L Shaped Bracket (Part C) onto it using 1 of the Metal Screws (Part E) Refer to Fig 1.



Place the Small Screw and Plastic Lock (Part D) into the Base Arm (Part A) in the opening and use the the opening and use the Tool to screw into the Top Mounting Arm (Part B). You may then use the other Large Metal Screw (Part E) and connect both Metal Mounting Arms through L Shaped Bracket) Part C) Refer to Fig 2 and 3.





3

Connect the Mounting Clamp (Part F) to the Base Mounting Arm (Part A) using the Thin Screws and Washers (Part G). You may now also slightly screw in the 4 Large Plastic Screws (Part H). Refer to Fig 4.



You may now slide the **Rubber Locking Nuts** (Part J) into the Top **Mounting Arm and once** in position you can lock them into place using the Tool. Refer to Fig 5.



Fig. 5











X4 REAR ARM INSTRUCTIONS



5

Get your Illumagic X4 Device (not supplied) and remove the 4 screws in the middle of the device. Now place the X4 Slider onto the X4 and fix using the 4 small screws supplied. Refer to Fig 6.



6

You may now proceed to screw the X4 onto the Mounting arm through the Rubber Locking Nuts using the remaining Large Metal Screws (part E). Refer to Fig 7.



Fig. 7

HANDY TIPS

If your glass is too thick, you may remove the rubber covers on the front of the Rear Arm and very carefully reinstall onto your aquarium, be very careful not to scratch your glass as it is a tight fit.











